

GENUINE COMFORT

GC-THOS-0-1

Instruction Manual

Wireless Thermostat

THEMOSTAT QUICK REFERENCE

Thermostat



Receiver



Table of Contents

	Page
Thermostat quick reference	1-3
Installation tips	4-8
Wiring diagrams	9-11
Technician setup	12-17
Thermostat paired	18

support.genuinecomfort.com



THEMOSTAT QUICK REFERENCE

Thermostat Applications Guide

Description	
Gas or Oil Heat	Yes
Electric Furnace	Yes
Heat Pump (No Aux. or Emergency Heat)	Yes
Heat Pump (With Aux. or Emergency Heat)	Yes
Multi-Stage Systems	Yes
Heat Only Systems	Yes
Heat Only Systems - Floor or Wall Furnace	Yes
Cool Only Systems	Yes
Millivolt Conventional Systems	No
Two Transformer Systems	No

Power Type


Thermostat:DC3V/24VAC
Receiver:24VAC

Specifications


The display range of temperature	----- 32°F to 99°F (0°C to 40°C)
The control range of temperature	----- 41°F to 90°F (5°C to 32°C)
Humidity display range	----- 0%-99%
Load rating	----- 1 amp per terminal, 1.5 amp maximum all terminals combined
Display accuracy	----- ± 1°F
Swing (cycle rate or differential)	----- Heating is adjustable from 0.2°F to 2.0°F Cooling is adjustable from 0.2°F to 2.0°F
Power source	----- 18 to 30 VAC, NEC Class II, 50/60 Hz for hardwire (common wire) Battery power from 2 AA Alkaline batteries
Operating ambient	----- 32° to +105° (0° to +41°C)
Operating humidity	----- 90% non-condensing maximum
Dimensions of thermostat	----- 4.7"Wx3.8"Hx1.1"D
Dimensions of Receiver	----- 3.9"Wx1.8"Hx1.0"D
Wireless operating frequency	----- 915MHZ

THEMOSTAT QUICK REFERENCE

Getting to know your thermostat



- 1 LCD Display
- 2 Fan Switch
- 3 System Switch
- 4 Set-Point Buttons
- 5 (PIR) Human body sensor detection window
- 6 Temperature unit switching button



- 1 Displays the user selected set-point temperature
- 2 Indicates the current room temperature
- 3 Fan mode indication
- 4 System mode indication
- 5 Fan run indication
- 6 cool run indication
- 7 heat run indication
- 8 WIFI indication

INSTALLATION TIPS

IMPORTANT SAFETY INFORMATION WARNING

- Always turn off power at the main power source by unscrewing fuse or switching circuit breaker to the off position before installing, removing cleaning, or servicing thermostat.
- Read all of the information in this manual before installing or programming this thermostat.
- This is a 24V AC low voltage thermostat. Do not install on voltages higher than 30V AC
- All wiring must conform to local and national building and electrical codes and ordinances.
- Do not short (jumper) across terminals on the gas valve or at the system control to test installation. This will damage the thermostat and void the warranty.




Mercury Notice:

This product is mercury-free. However, if this product is replacing a control which contains mercury, it needs to be disposed of properly. Contact your local waste management authority for instructions regarding recycling and proper disposal of the control.


INSTALLATION TIPS

Unfold the thermostat




1.Remove the screw with a screwdriver

2.Separate the front casing from the back casing



INSTALLATION TIPS

Installation wiring board



1 Horizontal Mount:

For a horizontal mount, put screws on the left and right.

2 Vertical Mount:


For a vertical mount, put screws on the top and bottom.

Drill 3/16-in. holes for drywall
Drill 3/16-in. holes for plaster



Caution: Electrical Hazard

Disconnect power before installing this product. Failure to do so can cause electric shock or equipment damage.



1. Press the handle
3. Release the handle

2. Insert the wire




Wiring Tips

Use wires of 20 to 26 AWG gauge.
No shielded wires are needed.

INSTALLATION TIPS

Install the receiver



Note:

The base module may be mounted using adhesive tape, such as double-sided tape or hook and loop strips. The base module must be hardwired (C & R terminals connected to 24V power). Use a secondary source of securement to prevent module from dropping into condenser drain pan.

Connecting to a PTAC:

When connecting the Base Module to a PTAC, refer to the PTAC manufacturer instructions to enable remote thermostat operation.




Wiring Note:

The base module is packaged with labeled thermostat wire. Wire appropriately into the PTAC board terminals.

INSTALLATION TIPS

Battery Installation




Battery installation is optional if used with AC power (the C terminal is connected). During power outages, the batteries will save settings and power the display.

Important:


High quality alkaline batteries are recommended. Rechargeable batteries or low quality batteries are not recommended.

Insert 2 AA high-quality alkaline batteries



Install thermostat

1. Install the thermostat on to the wiring board
2. Tighten the screws
(To remove the terminal board, you must unscrew this screw.)



WIRING DIAGRAMS

Terminal Designations


Terminal	Wiring port function					
R	Transformer power-24VAC					
C	Transformer common port (24VAC)					
O/B	Reversing Valve/Configurable Terminal					
GH	Fan control port --- High speed					
GL	Fan control port --- low speed					
		Level 1 heating	Level 2 heating	Level 1 cooling		
Heat Pump OFF	1H1C	W		Y		
Heat Pump ON	1H1C	Y		Y		
	2H1C	Y	W	Y		

WIRING DIAGRAMS


- 1 Power supply
- 2 Jumper(not supplied) to connect GL and GH terminals.
- 3 Thermostat must be set to O and B to match the changeover valve, O is the cool changeover valve, B is the heat changeover valve.
- 4 The Aux Heat Relay is energized as the second stage of heat

HEAT PUMP OFF

Typical 1H/1C System: 2 Speed Fan




Typical 1H/1C System: 1 Speed Fan




Note:

Most PTAC systems support two speed fan operation. In a single speed fan PTAC system or conventional single speed fan system, a jumper should be installed between GL and GH on the thermostat.

Typical 1H/1C Heat Pump System:2 SpeedFan



Typical 2H/1C Heat Pump System:2 SpeedFan



TECHNICIAN SETUP

Restore factory Settings:

Press and hold the “-” button, turn on the power, and release the factory Settings after the display is normal.

HEAT SWING

Select HEAT with the system switch, hold down the + and - buttons together for 3 seconds to access the HEAT SWING setting. Use the + or - key to adjust the swing from $\pm 0.2^{\circ}\text{F}$ to $\pm 2^{\circ}\text{F}$. Wait approximately 15 seconds or slide the system switch to return to normal operation.

COOL SWING

Select COOL with the system switch, hold down the + and - buttons together for 3 seconds to access the COOL SWING setting. Use the + or - key to adjust the swing from $\pm 0.2^{\circ}\text{F}$ to $\pm 2^{\circ}\text{F}$. Wait approximately 15 seconds or slide the system switch to return to normal operation.

TECHNICIAN SETUP

Technician Setup Menu

1. Set the thermostat system switch to OFF
2. To enter Tech Setup Menu, press and hold "+" and "-" together for 3 seconds
3. Use "+" or "-" to select desired setting for each option.
4. Tap "+" and "-" together to move next option.
5. To exit Tech Setup Menu, move system switch or wait for 15 seconds.

Tech Setup Steps		LCD Will Show	Adjustment Options	Default
Pair	Thermostat and receiver pair code		Press and hold the "+" key for 3 seconds to pair See: Thermostat paired	
Room Temperature Calibration	This feature allows the installer to change the calibration of the room temperature display. For example, if the thermostat reads 70° degrees and you would like it to read 72° then select +2.		You can adjust the room temperature display to read 4° above or below the factory calibrated reading.	


TECHNICIAN SETUP

Tech Setup Steps	LCD Will Show	Adjustment Options	Default
Compressor Short Cycle Delay	The compressor short cycle delay protects the compressor from short cycling. This feature will not allow the compressor to be turned on for 5 minutes after it was last turned off	 Selecting "ON" will not allow the compressor to be turned on for 5 minutes after the last time the compressor was switched off. Select "OFF" to remove this delay.	
Change Over Valve Selection	Select 0 for a changeover valve that energizes in cooling. Select b for a change over valve that energizes in heating	 0 for cooling changeover valve b for heating changeover valve	
Heat Pump	When turned on the thermostat will operate a heat pump. Y will be the first stage of heat & cool, W will be the second stage of heat.	 OFF configures the thermostat for non heat pump systems. ON configures the thermostat for heat pump systems.	
Heating Temperature Setpoint Limit	This feature allows you to set a maximum heat setpoint value. The setpoint temperature cannot be raised above this value.	 Use the - or + key to select Range : 41°F-90°F 5°C-32°C	

TECHNICIAN SETUP

Tech Setup Steps	LCD Will Show	Adjustment Options	Default
Cooling Temperature Setpoint Limit	This feature allows you to set a minimum cool setpoint value. The setpoint temperature cannot be raised above this valve.	 Use the - or + key to select Range :41°F-90°F 5°C-32°C	
Fan Operation	Gas is selected so that the thermostat does not turn on the fan while heating ELEC was chosen to enable the thermostat to be controlled to turn on the fan while heating	 Use the - or + key to select ELEC or GAS	
(PIR) energy saving mode	Select OFF: Turn off this feature Select ON: Once a room is declared vacant by PIR human sensors, The PTAC opportunity undergoes three stages of energy saving adjustment.	 Use the - or + key to select ON or OFF	

TECHNICIAN SETUP

Tech Setup Steps		LCD Will Show	Adjustment Options	Default
Energy saving phase 1 (Time setting)	Once a room is declared vacant by PIR human sensors,Start the timing, When the timing meets the S1 time, the section is adjusted according to the temperature set by S1. The unit is: hours		Use the - or + key to select 0.5-24hours	
Energy saving phase 1 (Temperature setting)	The unit is: Fahrenheit or Celsius		Use the - or + key to select 0-20°	
Energy saving phase 2 (Time setting)	Once a room is declared vacant by PIR human sensors,Start the timing, When the timing meets the S2 time, the section is adjusted according to the temperature set by S2. The unit is: hours		Use the - or + key to select 0.5-24 hours	

TECHNICIAN SETUP

Tech Setup Steps		LCD Will Show	Adjustment Options	Default
Energy saving phase 2 (Temperature setting)	The unit is: Fahrenheit or Celsius		Use the - or + key to select 0-20°	
Energy saving phase 3 (Time setting)	Once a room is declared vacant by PIR human sensors, Start the timing. When the timing meets the S3 time, the section is adjusted according to the temperature set by S3. The unit is: hours		Use the - or + key to select 0.5-24 hours	
Energy saving phase 3 (Temperature setting)	The unit is: Fahrenheit or Celsius		Use the - or + key to select 0-20°	


THERMOSTAT PAIRED

The thermostat and receiver come factory linked out of the box. If however, communication is lost, follow this easy- **Two Step** process to re-establish the communication link.


1.Receiver: Press and hold the receiver learning button for 3 seconds. The Red LED will flash when it is ready to receive the paired signal from the Thermostat. (Receiver must be 24V powered).

2.Transmitter: Turn the **SYSTEM** switch to **OFF**. Press and hold “+” and “-” to gether “**LE**” is displayed onthe LCD.Then press and hold “+” for 3 seconds for 3 seconds the Thermostat will transmit the code signal. When the red LED onthe receiver stops flashing,Indicates a successful pairing.

Step 1.



Step 2.



Instruction Manual